

# **OBSIDIAN** *Wire*



- 1) Clip output, ground and pickup wires from your old harness. Make the cut as close to the current harness terminals as possible (DO NOT REMOVE GROUND WIRES AT GUITAR END).
- 2) Strip wires, leaving 5mm (1/6") to be inserted into the easy connector. No more, no less.
- 3) Press easy release button with a fine screw driver and firmly press wire into terminal (following wire map above).
- 4) Lightly pull each wire to test for a secure connection. If it pops out, try again. When the wire is inserted correctly it will hold strong.
- 5) Re-install your control plate, string up and enjoy.

Handy Hint: If you are re-installing a set of wires and they are not going in as easy as the first time repeat step 1 & 2.

**If you have any trouble please visit our website [ObsidianWire.com](http://ObsidianWire.com) for some visual instructions, or contact Mathew at – [mathew@obsidianwire.com](mailto:mathew@obsidianwire.com). We will be happy to help.**

# ***OBSIDIAN*** *Wire*

SOLDER NEW WIRE HERE



CLIP THIS LINK

If you have any trouble please visit our website [ObsidianWire.com](https://ObsidianWire.com) for some visual instructions, or contact Mathew at – [mathew@obsidianwire.com](mailto:mathew@obsidianwire.com). We will be happy to help.