


WARNING:

We use US spec, 24 spline controls.
DO NOT use small metric knobs as found on import and some US model guitars. They will destroy your new Pro-Wired Electronics.

OBSIDIAN Wire



- 1) Clip output, ground and pickup wires from your old harness. Make the cut as close to the current harness terminals as possible (DO NOT REMOVE GROUND WIRES AT GUITAR END).
- 2) Strip wires, leaving 5mm (1/6") to be inserted into the easy connector. No more, no less.
- 3) Press easy release button with a fine screw driver and firmly press wire into terminal (following wire map above). Use pickup manufacturers instructions to identify each wire as they vary from builder to builder.
- 4) Lightly pull each wire to test for a secure connection. If it pops out, try again. When the wire is inserted correctly it will hold strong.
- 5) Insert additional ground wires into screw down ground connector and you are all done. Enjoy.

Handy Hint: If you are re-installing a set of wires and they are not going in as easy as the first time repeat step 1 & 2.

If you have any trouble please visit our website ObsidianWire.com for some visual instructions, or contact Mathew at – mathew@obsidianwire.com. We will be happy to help.